

Operation and maintenance of Helvar products



Helvar products should normally be cleaned according to the defined maintenance plan proposed by the building maintenance services. Surfaces ought to be cleaned when dust and other grime is discovered. The following should be taken into consideration to ensure a good result:

- Ensure that the product is ventilated and ambient operating temperatures are within the product guidelines.
- Make sure that the product is free from dust and particle build-up.
- Ensure that the product is not subjected to high levels of humidity.
- For control panel fascia or similar products, cleaning should only be carried out with a neutral cleaning agent, to prevent damage to the plastic or metal surfaces of the fascia.

Notice:

Electrical components or cabling must not be exposed to cleaning agent or water. It is important to always disconnect the voltage before cleaning.