

Recommended PC Specification For Helvar Software

Min. Hardware Requirements	Designer V4.x.x.x	Designer V5.x.x.x	Toolbox
Pentium III based or Later			
512MB RAM or more			
10/100 Ethernet network adaptor			
Mouse or other pointing device			

Min. Operating System	Designer V4.x.x.x	Designer V5.x.x.x	Toolbox
Windows XP			
Windows Vista			
Windows 7	\		
Windows 8			
Windows 10		✓	
Windows 11	Untested	Untested	Untested